

## Yacht Equipment

### Electricity

- Inverter
- Solar system
- Plug 220V, 12 V. 5V
- Shore connection 220 V
- Battery charger

### Galley

- Stove
- Refrigerator
- Kitchen utensils (Galley equipment, cutlery)
- Oven

### Leisure

- Bimini top
- Radio CD player
- Cockpit/stern, outside shower
- Snorkeling equipment
- Spray hood
- Outside speakers
- Gangway
- Cockpit cushions
- Hot water
- Swimming ladder
  
- Dinghy
- Outboard engine 2.5 HP Suzuki
- SUP (**Optional extra**)

## Navigation

- Bow thruster
- Electric anchor windlass
- Pilot book
- Nautical charts
- Cockpit table
- Autopilot
- Navigation set
- List of lights
- GPS chart plotter
- Speedometer (Speed log)
- Depth sounder
- VHF radio
- Wind instrument/Anemometer

## Safety

- AIS class A
- EPIRB-Distress radio beacons
- Life raft
- Safety Net for children (**optional extra**)
- Life Vests